



Install Instructions

AllTight™ Weather Protection System
For 1-5/8" to 1/2" Connections

Materials



PORT SEAL




WPS-4A / WPS-4S



1/2" AllTight™ CONNECTOR



1-5/8" AllTight™ CONNECTOR



WPS-7



ADJUSTABLE WRENCH
OR
1-1/2" OPEN ENDED WRENCH



TQ-114-F18
TORQUE WRENCH

Step #1 Install



Slide the WPS-7 onto the 1-5/8" cable 6-12 inches from the end prior to cable preparation.



Place the 1/2" to 1-5/8" coupler onto the cable as shown. Next, slide the WPS-4A or WPS-4S onto the 1/2" cable 6-12 inches from the end prior to cable preparation.

Step #2 Install Connectors



Prep and install the 1-5/8" cable to install the AllTight™ compression connector. Refer to the 1-5/8" corrugated connector install instructions.



Place the port seal onto the female connector.



Properly installed port seal.



Prep and install the 1/2" cable to install the AllTight™ compression connector. Refer to the 1/2" corrugated connector install instructions.



Install Instructions

AllTight™ Weather Protection System

For 1-5/8" to 1/2" Connections

Step #3 Connect and Torque Interface



Install the 1-5/8" connector to the 1/2" connector.



Torque the connection to 18 ft-lbs using the TQ-114-F8 torque wrench and an adjustable wrench or 1-1/2" open ended wrench.



Properly installed connector.

Step #4 Install WPS-4A or WPS-4S



Slide the WPS-4A or WPS-4S over the 1/2" connection making sure to overlap the port seal.



The WPS-4A or WPS-4S should cover the port seal entirely as shown.



Install the 1-5/8" to 1/2" coupler to the WPS-4A or WPS-4S.



Properly installed coupler. Note that the coupler rests flush against the 1-5/8" connector.

Step #5 Install WPS-7



Slide the WPS-7 over the 1-5/8" connector and slide onto the coupler.



Completed installation of the AllTight™ Weather Protection System.